

UNIT DESCRIPTION:

41A5 1893 Connector Mate/Demate Log

Connector(s)	Authorized by	Date	Mate or Demate	Flight or Test	Verify Power Off	Pre-mate Inspect	ESD Bleed and Connector Mate	Final Inspect
Connector Reference Designator	Procedure & para or NCR	M/D/Y	M or D	F or T	Emp. ID#	*Emp. ID#	*Emp ID#	*Emp. ID#
IC-0	MD 6069	02/21/15	M	F	SW	SW	SW	SW
IC-1				F				
IC-2				F				
IC-3				F				
JT-0				F				
JT-1				F				
JT-2				F				
JT-3				F				
JT-4				F				
JT-5				F				
JT-6				F				
JT-7				F				
J-1				F				
JS-1				F				

*Personnel that is Mate/Demate certified.

Connector /Bracket R/D:

UNIT DESCRIPTION:

6151 1843 Connector Mate/Demate Log

Connector(s)	Authorized by	Date	Mate or Demate	Flight or Test	Verify Power Off	Pre-mate Inspect	ESD Bleed and Connector Mate	Final Inspect
Connector Reference Designator	Procedure & para or NCR	M/D/Y	M or D	F or T	Emp. ID#	QA	* Emp ID#	* Emp. ID#
IC-0	NO	6/29/15	D	F	800	QA	800	800
IC-1				F		QA		
IC-2				F		QA		
IC-3				F		QA		
JT-0				F				
JT-1				F				
JT-2				F				
JT-3				F				
JT-4				F				
JT-5				F				
JT-6				F				
JT-7				F				
J-1				F				
JS-1				F				

* Personnel that is Mate/Demate certified.

Connector /Bracket R/D:

TEM/TPS Performance Test Procedure

Appendix B Connector Mate/Demate Log

CONNECTOR MATE / DEMATE

UNIT DESCRIPTION: GLAT 1843

Connector(s)	Authorized by	Date	Mate or Demate	Flight or Test	Verify Power Off	Pre-mate Inspect	ESD Bleed and Connector Mate	Final Inspect
Connector Reference Designator	Procedure & para or NCR	M/D/Y	M or D	F or T	Emp. ID#	QA	* Emp ID# QA	* Emp. ID# Witness Stripe Torqued, Witness Stripe applied
JC-0	ND 619	4/23/5	M	F	SD	QA	SD	QA
JC-1								
JC-2								
JC-3								
JT-0								
JT-1								
JT-2								
JT-3								
JT-4								
JT-5								
JT-6								
JT-7								
JT-8								
JT-9								
JT-10								
JT-11								
JT-12								

*Personnel that is Mate/Demate certified.

Connector /Bracket R/D:

Note: This Mate/Demate log is a Microsoft Excel file embedded in the Microsoft Word version of this document. The file can be copied and pasted into a folder and then opened as an Excel worksheet.

Hard copies of this document are for REFERENCE ONLY and should not be considered the latest revision.